

EXPERIMENT 20: ALERT SYSTEM USING TAG

Objective: The objective of this experiment is to create an alert system using an RFID tag. The system should detect the RFID tag, and upon detection, it sends a message to a Bluetooth app. Additionally, the robot can be controlled to move forward when a button is pressed.

Setup:

- Assemble the robot hardware according to the instructions in Section 2.1.
- Connect the robot to the Arduino IDE as explained in Section 2.3.
- Establish the following hardware connections:

RFID Reader:

For detailed instructions on connecting the RFID reader to the Arduino, please refer to the following link provided :[RFID reader to the Arduino . Follow this link to download the library MFRC522.](#)

- SS_PIN: Connect to digital pin 10.
- RST_PIN: Connect to digital pin 5. for the

Bluetooth Module:

- RX_PIN: Connect to digital pin 1.
- TX_PIN: Connect to digital pin 0.

Motor A:

- IN1: Connect to digital pin 8.
- IN2: Connect to digital pin 9.

Motor B:

- IN3: Connect to digital pin 10.
- IN4: Connect to digital pin 11.

Push Button:

- BUTTON_PIN: Connect to digital pin 7.
- Initialize the RFID reader, Bluetooth communication, and motor pins in the setup.

Code Example: [Alert System Using RFID Tag](#)

Usage Instructions:

- Power the robot and ensure it is connected to the Arduino.
- Bring an RFID tag close to the RFID reader and tap it.
- If the RFID tag is detected, the UID will be displayed on the serial monitor, and a message will be sent to the Bluetooth app saying "Robo passes."
- Press and hold the push button to move the robot forward.
- Release the push button to stop the robot.

Expected Results:

- The system should respond to the RFID tag by sending a message to the Bluetooth app.
- Pressing the push button should make the robot move forward, and releasing the button should stop the robot.

FAQs:

Q: How do I ensure the RFID tag is detected?

A: Bring the RFID tag close to the RFID reader and tap it. Check the serial monitor for UID information.

Q: Can I customize the message sent to the Bluetooth app?

A: Yes, modify the `bluetoothSerial.println("Robo passes");` line in the code for different messages.

Q: How can I modify the code for different motor speeds?

A: Adjust the PWM values (e.g., `analogWrite(ENA, 200) ;`) for both motors based on your speed requirements.